

HOW TO USE...

CUT TIDY

Cut Tidy is a fabulous way to cut your intricate dies without getting little pieces of paper everywhere. It also works well with paper, which has previously been difficult to use in intricate dies due to tearing.



1. Place the die, cutting side up, on the base plate and place the open Cut Tidy folder over the top.



2. Position the paper over the die, but inside the folder, and close the folder.



3. Run the die through the machine. Repeat as necessary depending on the intricacy of the die.



4. Gently peel the top layer of the folder back, the waste will start to come away with the folder.



5. Gently peel the die cut away from the die. Do not peel the die away from the folder.



6. Tip the waste into the bin.

PLEASE NOTE: Your folder is reusable for several cuts, dependant on the pressure of the sandwich and weight of the paper / card.